

PART# 23005
(Formerly UVS100)




HOW TO USE

Complete the set up of your repair assembly over the break. Just before dispensing resin into the injector, position the Sun Shield to effectively block sun or bright daylight from the immediate area of the repair. Fasten shield to the glass with one or more of the 4 suction cups. Work under the protection of the UV Shield until you have applied curing tape to the repair and are ready for the final curing process to begin. Remove the UV Shield and allow the sun or other UV source to complete the curing process.



Order from your local
supplier of Delta Kits
products, or call
Delta Kits Inc.
800-548-8332



DELTA KITS INC
EUGENE, OR 97402

PART# 23005
(Formerly UVS100)



HOW TO USE

Complete the set up of your repair assembly over the break. Just before dispensing resin into the injector, position the Sun Shield to effectively block sun or bright daylight from the immediate area of the repair. Fasten shield to the glass with one or more of the 4 suction cups. Work under the protection of the UV Shield until you have applied curing tape to the repair and are ready for the final curing process to begin. Remove the UV Shield and allow the sun or other UV source to complete the curing process.



Order from your local
supplier of Delta Kits
products, or call
Delta Kits Inc.
800-548-8332



DELTA KITS INC
EUGENE, OR 97402