



## 16150 Ignite Mount OPERATING INSTRUCTIONS

### **To Attach:**

Be sure the glass and the rubber pad on the mount are clean and dry. With the flip lever in the up position, hold the mount securely to the glass and latch the flip lever into the down "locked" position. Insure that the mount is firmly attached to the glass. The arm has four adjustment points to locate the Ignite UV Light into the desired location. Install the Ignite UV lamp into the holding clip for the proper positioning of the lamp. The location of the lamp should be approximately 1/4" above the surface of the area to be cured.

### **To Remove:**

Remove the Ignite UV light from the holding clip. Flip the lever to the up position. The mount is equipped with a release tab located on the cups outer edge. This tab must be used to remove the 16150 mount to avoid causing possible damage to the mount body. Place your finger between the release tab and the glass surface until the mount has been released from the glass by gently pulling tab in an upward motion.

### **CAUTION**

**DO NOT** remove the mount without using the release tab!

**DO NOT** remove the mount by twisting or pulling on the mount body, this could cause failure of the mount and void the 30 day warranty.

